




1. Turn Pet off and unplug power outlet.
2. Remove 2 screws holding cover to base. (see figure I).



3. Assemble 4 standoffs with 4 phillips head screws, and set aside. (see figure II).




4. Using a small chisel head screwdriver, remove device 6502 MPU from position UB14 on the main CPU board. (save 6502)
5. Install flat ribbon cable into UB14 on main CPU board (replacing the removed 6502). Position cable such that it is facing front of computer.
6. Install long power harness to J11 on main CPU board. (note polarity). Position harness towards front of computer.
7. Install short harness to J10 on main CPU board. (note polarity).
8. Ascertain that the 3 cables are positioned towards front of computer.
9. Install the 64K memory add-on board over the main CPU board such that slotted side is on right hand side of computer.
10. Position standoffs such that, the 2 long ones straddle the edge of the computer base, while the 2 short ones straddle the main CPU board heat sink. (see figure III).



11. With Allen wrench tool tighten 4 sets screws on standoffs to secure add-on board.
12. Connect flat ribbon cable to edge connector on 64K add-on board.
13. Connect the long power harness to J2 on 64K board.(note polarity).
14. Connect the short harness to J1 on the 64K board. (note polarity).
15. Loosen 4 standoff screws and adjust board to it's left most position, retighten 4 screws.
16. Close Pet cover & reinstall 2 screws to secure cover to base.


Note: At times the inside of the cover may rub the edge of the board during opening and closing of the computer cover.

REVISIONS			
LTR	ZONE	DESCRIPTION	DATE
A		PRODUCTION RELEASE	3/3/74
B		REV PER ECO 2144	7/6/74



UNLESS OTHERWISE SPECIFIED		DRAWN BY	DATE
TOLERANCES	DECIMAL	ENGR	APPR
X	1	2	3
MATERIAL	FINISH	USED ON	NEXT ASSY
commodore			
INSTALLATION			
MEMORY, PET 64K			
SIZE	C	8032100	REV A
SCALE 1/2		SHEET 1 OF 1	

REVISIONS		DATE	APPROVED
1	DATE		
2	DESCRIPTION		



NOTES:

- 1 PART OF STANDOFF'S
- 2 STAND OFF (PIN 907169-02)
LENGTH 1.312 INCHES
- 3 STAND OFF (PIN 907169-01)
LENGTH 1.062 INCHES
- 4 CABLE, FLAT RIBBON
(PIN 8032096-01)
- 5 CABLE ASSY, HARNESS (LONG)
(PIN 8032097-01) J2-J11
- 6 CABLE ASSY, HARNESS (SHORT)
(PIN 8032098-01) J11-J10

COMMODORE		DATE	BY
1	DATE		
2	DESCRIPTION		
3	DATE		
4	DESCRIPTION		
5	DATE		
6	DESCRIPTION		
7	DATE		
8	DESCRIPTION		
9	DATE		
10	DESCRIPTION		
11	DATE		
12	DESCRIPTION		
13	DATE		
14	DESCRIPTION		
15	DATE		
16	DESCRIPTION		
17	DATE		
18	DESCRIPTION		
19	DATE		
20	DESCRIPTION		
21	DATE		
22	DESCRIPTION		
23	DATE		
24	DESCRIPTION		
25	DATE		
26	DESCRIPTION		
27	DATE		
28	DESCRIPTION		
29	DATE		
30	DESCRIPTION		
31	DATE		
32	DESCRIPTION		
33	DATE		
34	DESCRIPTION		
35	DATE		
36	DESCRIPTION		
37	DATE		
38	DESCRIPTION		
39	DATE		
40	DESCRIPTION		
41	DATE		
42	DESCRIPTION		
43	DATE		
44	DESCRIPTION		
45	DATE		
46	DESCRIPTION		
47	DATE		
48	DESCRIPTION		
49	DATE		
50	DESCRIPTION		
51	DATE		
52	DESCRIPTION		
53	DATE		
54	DESCRIPTION		
55	DATE		
56	DESCRIPTION		
57	DATE		
58	DESCRIPTION		
59	DATE		
60	DESCRIPTION		
61	DATE		
62	DESCRIPTION		
63	DATE		
64	DESCRIPTION		
65	DATE		
66	DESCRIPTION		
67	DATE		
68	DESCRIPTION		
69	DATE		
70	DESCRIPTION		
71	DATE		
72	DESCRIPTION		
73	DATE		
74	DESCRIPTION		
75	DATE		
76	DESCRIPTION		
77	DATE		
78	DESCRIPTION		
79	DATE		
80	DESCRIPTION		
81	DATE		
82	DESCRIPTION		
83	DATE		
84	DESCRIPTION		
85	DATE		
86	DESCRIPTION		
87	DATE		
88	DESCRIPTION		
89	DATE		
90	DESCRIPTION		
91	DATE		
92	DESCRIPTION		
93	DATE		
94	DESCRIPTION		
95	DATE		
96	DESCRIPTION		
97	DATE		
98	DESCRIPTION		
99	DATE		
100	DESCRIPTION		

scanned by
steve gray